

FREQUENTLY ASKED QUESTIONS (FAQ)	iv
CHAPTER I - GETTING STARTED	1-1
1.1 Installing ASAD for the First Time	1-1
1.1.1 Installing the ASAD Program	1-1
1.1.2 Installing the Locking Mechanism	1-1
1.2 Starting a new Drainage Project	1-3
1.2.1 Creating A New Drainage System Database	1-3
1.2.2 Setting File Locations (Top & Report files, Cell Libraries)	1-4
1.2.3 Working in Concert with MicroStation and GEOPAK	1-5
1.2.4 Project Setup Tips	1-5
1.2.5 Migrating from version 2 to version 3	1-5
1.2.6 Rebuild Project Database to Maintain Database Integrity	1-6
1.3 Working with the ASAD Controls	1-8
1.3.1 Main Program Window	1-8
1.3.2 Pulldown Menu Summary	1-9
1.3.3 Floating Toolbars	1-9
1.3.4 Floating Toolbar Icons and Functions Summary	1-9
CHAPTER II - ASAD EDITING COORDINATE GEOMETRY	2-1
2.1 Baselines	2-1
2.1.1 Importing Baselines	2-2
2.1.1.1 COGO Input Files	2-2
2.1.2 Data Required	2-3
2.1.3 Baseline Tangent Intersection Calculator	2-6
2.1.4 Verify Baseline Geometry (By Drawing in CAD)	2-6
2.2 Profiles	2-7
2.2.1 Importing Profiles	2-8
2.2.2 Verify Profile Geometry (By Displaying)	2-8
2.3 Cross Slopes	2-9
2.4 Cross Widths	2-10
CHAPTER III - ASAD HYDROLOGY	3-1
3.1 Defining a Drainage Basin	3-1
3.1.1 Adding, Deleting, Renaming a Storm Sewer System	3-1
3.1.2 Outfall and Header Details	3-2
3.1.3 Dividing and Combining Systems	3-4
3.2 Node/Reach Automatic Creation	3-6

3.3	Node Edit	3-8
3.3.1	Editing Nodes: Type 'Structure'	3-8
3.3.2	Editing Nodes: Type 'Ditch'	3-12
3.3.3	Defining Node Structure Characteristics	3-12
3.3.4	Developing Hydrologic Basin Areas and Calculating Tc	3-13
3.4	Reach Edit	3-15
3.4.1	Editing Reaches – Data Common to All Types	3-15
3.4.2	Editing Reaches – Solid Pipes	3-16
3.4.3	Editing Reaches – Perforated Pipes w/Exfiltration Trench	3-17
3.4.4	Editing Reaches – Ditches & Swales	3-19
3.4.5	Percolation Borings	3-20
3.5	Node and Reach Renumbering	3-22
3.6	Structure Definitions	3-25
3.6.1	Drawing (tab)	3-26
3.6.2	Annotation (tab)	3-28
3.6.3	Dimensions (tab)	3-30
3.6.4	Hydraulics (tab)	3-31
3.6.5	Quantity/Cost (tab)	3-31
3.6.6	Other (tab)	3-33
3.7	Pipe Definitions	3-34
3.8	Importing Node and Reach Data from other Programs	3-34
CHAPTER IV - ASAD GEOMETRY AND HYDRAULICS CALCULATIONS		4-1
4.1	Compute Storm Sewer Geometry and Drainage Areas	4-1
4.2	Compute Pipe Sizes	4-2
4.3	Set Flow Lines	4-3
4.4	Compute Hydraulics and Generate Storm Tabs	4-5
4.5	Utility Conflicts	4-8
4.6	Storm Sewer Cost Analysis	4-9
4.7	Profile Elevation Inquiry	4-9
CHAPTER V - ASAD CAD		5-1

5.1	Files	5-1
5.1.1	Manipulating a MicroStation version 8 DGN Files	5-1
5.1.2	Reference Files	5-1
5.1.3	Plotting	5-1
5.1.4	View Control	5-2
5.1.5	Model Space	5-2
5.1.6	Level Names & ASAD Master Level List	5-3
5.1.7	Snapping to Elements & SmartPick	5-3
5.1.8	Display DataPoint: North, East, Station, Offset, Elevation	5-3
5.2	Storm Sewer Graphics	5-5
5.2.1	Drawing in Plan View	5-5
5.2.1.1	Drainage Systems	5-5
5.2.1.2	Drainage Area Boundaries	5-8
5.2.1.3	Cross Section Pattern Lines	5-9
5.2.1.4	General Level/Symbology	5-11
5.2.2	Drawing in Profile View	5-14
5.2.3	Drawing in Cross Section View (Drainage Structures)	5-17
5.2.3.1	Mode – Single Structure: DP Exact or Relative	5-17
5.2.3.2	Mode – Multiple Structures: GEOPAK Cross Section Cells	5-17
5.2.3.3	Mode – Multiple Structures: Plan Drawing	5-19
5.2.3.4	Mode – Multiple Structures: Grid Layout	5-20
5.2.3.5	Settings, Line Level/Symbology, Labels	5-21
5.2.4	Drawing Summary of Drainage Structure Sheets (SDS)	5-25
5.2.4.1	Step 1: Clear Column Setup	5-25
5.2.4.2	Step 2: Scan Database and Build SDS Table	5-26
5.2.4.3	Step 3: Reset ALL Levels to FDOT Standards	5-26
5.2.4.4	Step 4: Compute Text Size, Row, Column & Sheet Spacing	5-27
5.2.4.5	Step 5: Draw into CAD or Export to a Text File	5-28
5.2.4.6	SDS Data Table	5-29
5.2.4.7	Row Layout	5-30
5.2.4.8	Grid Layout	5-30
5.2.4.9	Headings & Symbology	5-31
5.2.5	Drawing Cells in a Grid	5-34

APPENDICES

A.	Step-By-Step User Flowchart	A-1
B.	History and Future of ASAD Locking Mechanisms	A-4
C.	Installing and Un-Installing the ASAD CAD Engine	A-6
D.	Installing the Hardware Lock	A-8